



# Plate No. 6

Part Ref. No.	Description of Part and Location on Plate	Quantity per mc.	Part Ref. No.	Description of Part and Location on Plate	Quantity per mc.
E.	8 Nut for Miller Cover and Miller Cover Hinge (AT-HS)	5	GS.	10060 Pin fixing Miller Sleeves on Miller Shaft and Miller Extensions (CP)	8
RP.	8 Washer for U Bolt 10896 (AU)	2	10265	Support to Mud Scraper Blades (AP)	2
RG.	8 Spring Washer for Miller Gearbox and Miller Cover Hinge (AU-HS)	5	10266 D	Blade to Mud Scraper, R.H.S. (AR)	1
CD.	300 Miller Tine, Hinged Light, Hook, Central (ER-ET-LS-KP)	14	10266 G	Blade to Mud Scraper, L.H.S. (AP)	1
CD.	301 Miller Tine, Hinged Light, Hook, Left (ET)	1	10267	Pivot for Mud Scraper Blades (BQ)	2
CD.	302 Miller Tine, Hinged Light, Hook, Right (LS)	1	10268 D	Spring to Mud Scraper Blade, R.H.S. (BR)	1
RD.	310 Miller Spring for Hinged Light Miller Tines (HQ-JQ-HU-JU)	16	10268 G	Spring to Mud Scraper Blade, L.H.S. (BP)	1
BD.	311 Lug for Hinged Light Miller Tines, L.H.S. (HP-GU-GV-JS-JV-KQ)	16	10299	Cover to Miller Gearbox (GS)	1
BD.	312 Lug for Hinged Light Miller Tines, R.H.S. (GQ-GU-JP-JQ-JU-KS)	16	10302	Crown Wheel (ES)	1
AD.	600 Pin for Hinged Miller Tines (GP-GQ-FS-FV-KP-KU-KV-JS)	16	10303	Bevel Pinion (BS)	1
S.	846 Stud fixing Miller Gearbox Cover (ES)	3	10304	Bronze Washer to Left of Crown Wheel (ES)	1
GY.	3090 Pin for Miller Springs (EQ)	16	10306	Miller Shaft (DR)	1
F.	3535 Split Pin to Mud Scraper (BQ)	2	10312 A	Miller Sleeve for Light Springs (HS)	2
	4511 A Peg for Miller Bushes (DT)	2	10313	Felt Washer inside Miller Sleeves (CQ-CT)	2
	5019 A Depth Shoe (DV)	1	10314	Paper Joint for Miller Gearbox Cover (FS)	1
	5246 Twist Pin for Locking Depth Bar (ET)	1	10315 A	Depth Regulating Bar (BT)	1
	5270 Nut fixing Depth Shoe (CU)	2	10393	Steel Thrust Washer to Bevel Pinion, rear (SC)	1
	5271 Bolt fixing Depth Shoe (CV)	2	10394	Bronze Thrust Washer to Bevel Pinion, front (CS)	1
R.	6016 Rivet to Mud Scraper (BR-AP)	4	10395	Bronze Washer to right of Crown Wheel (DS)	1
F.	6030 Split Pin fixing Hinged Miller Tine Pin (FQ-FV-KQ-KS-KU)	32	10396	Miller Sleeve Extension for Light Springs (JP-HV)	2
GS.	6050 Pin Fixing Miller Dog (AR)	1	10982	Flange to Miller Casing, alone (BS)	1
C.	6430 Key for Miller Dog (AS)	1	10983	Miller Gear Casing, alone (CS)	1
	7163 Pin Hinging Depth Regulating Bar (AV)	1	10984	Tube for Miller Casing, alone (BS)	1
C.	8645 Key for Crown Wheel (ES)	2	10986	U Bolt fixing Miller Cover Hinge and Mud Scraper (BU)	1
	10045 Miller Dog (AS)	1	10988	Bracket for Mud Scraper (AQ)	1
	10057 Bush to Bevel Pinion (BS-CS)	2	12207 D	Bush to Miller Shaft, R.H.S. (CR)	1
			12207 G	Bush to Miller Shaft, L.H.S. (DT)	1
			12218	Leather Washer to Miller Sleeve (CR-CT)	2
			910984	Miller Casing Assembly, without Gears, Bushes and Cover (AT)	1
			910988	Complete Mud Scraper Assembly (BP)	1